


Note: This interlock function cannot be used if security is required.

Interlock connection Kill=NO
for ASSA ABLOY SW100, ASSA ABLOY SW200 and
ASSA ABLOY SW300





Comfort Air Interlocking for
ASSA ABLOY SW100, ASSA ABLOY SW200
and ASSA ABLOY SW300

ASSA ABLOY
4.0 1015595-en

Note: This interlock function cannot be used if security is required.

Interlock connection Kill=NC
for ASSA ABLOY SW200 and ASSA ABLOY SW300



Comfort Air Interlocking for
ASSA ABLOY SW200 and
ASSA ABLOY SW300